

R5

Ø35

37

400

800

780

742

510 490 407

Oliveri

Cut out template: AP1491

Ensure template is the correct way up and in the correct position prior to marking out and cutting the benchtop

Please take care when installing this sink as an under-mount
Please assess bench-top material before proceeding with under-mount installation
Consult with your kitchen contractor for flushmount installation.

UNDERMOUNT CUTOUT
REFER TO BENCH TOP
SUPPLIER FOR
SUITABILITY OF
UNDERMOUNT
INSTALLATION AND TAP
HOLE POSITIONING.

INSET CUTOUT

FLUSH MOUNT REBATE
1.2MM USE ACTUAL SINK
FOR EXACT DIMENSIONS

R20

R19

