

Opal Progressive Pull Out Kitchen Set

Dimensions are nominal measurements only.







Versions: V1

SPECIFICATION

WELS RATING 6 STAR 4.5L/MIN

WATERMARK LICENSE WM-060073

TEMPERATURE RATING MIN 1°C-MAX 75°C

PRESSURE RATING MIN 150KPa-MAX 500KPa

FINISH



GRAPHITE

NR252008GR



BRUSHED BRONZE
NR252008BZ

BRUSHED NICKEL

NR252008BN

BRUSHED GOLD NR252008BG

MAINTENANCE AND CARE

All surfaces should be cleaned with mild liquid detergent or soap and water

Do not use cream cleaners or citrus based cleaning products, as they are abrasive.

Use of unsuitable cleaning agents may damage the surface. Any damage caused in this way will not be covered by warranty


PACKING INCLUDES

- 1x pull out sink spout
- 1x hand wheel
- 1x base ring
- 1x counter weight
- 1x triangular support
- 1x extension hose
- 2x flexible hose



Installation Instruction

1




1.Drill a 35mm (for spout) and a 40mm (for mixer) through-hole on the counter. (The counter thickness must between 20mm to 40mm)

The recommended distance of the two holes is 200mm, reference to below diagram.

 $2. \\ Remove all fitting parts on the thread pipe for both spout part and mixer part.$


Put on base ring for spout part, then put spout part and mixer part through the two holes.

2



- 3.8 lide rubber washer, triangle plate and steel washer and lock nut onto spout part in a row according above diagram. Then slide rubber washer and nut onto mixer part.
- 4. Screw on extension spray hose, hot and cold flexible hoses onto mixer part according to below diagram.
- $5. Connect \, pull \, out \, hose \, to \, extension \, hose \, by \, quick \, joint.$
- $6. In stall \ counter \ weight \ onto \ pull \ out \ hose \ firmly. \ The \ recommended \ in stall ation \ height \ of \ weight \ is \ 350 mm \ from \ the \ counter \ bottom \ side, \ please \ reference \ to \ below \ diagram.$

3



7. Turn the hand wheel counterclockwise to the end. Then reinstall the hand wheel, make the "C" should be on twelve o'clock direction and "H" on the six o'clock direction, according to above picture. Then tighten grub screw of hand wheel by allen key, put cap into hand wheel.